



## MICROCONTROLLER




QSPI. So you can use any GPIOs except P0.10, P1.06, P0.09, P1.03, P1.07, P1.05, P1.02, P1.04 and P1.01 without any problems what so ever


## FEATHER PINS




## USB




## REGULATOR



## BATTERY CHARGER



## FLASH MEMORY



Andres Sabas

Electronic Cats

Sheet: /  
File: BastBLE.sch

**Title: Bast BLE**

Size: A4 Date: 2020-01-15  
KiCad E.D.A. kicad (5.1.4-0-10\_14)

**Rev: 0.1**  
Id: 1/1